






| Optional Scans for CR1500 Scanner | |
|---|---|
| <p>1. Disable Suffix <ENTER></p>  <p>M20208_01</p> | <p>This code disables the suffix <ENTER>.</p> |
| <p>2. Continuous Scan ON</p>  <p>M20224_01</p> | <p>This code allows for continuous scanning on your CR1500.</p> |
| <p>3. 1 Second Scan Delay</p>  <p>M20230_01</p> | <p>This code creates a 1 second delay between scans.</p> |
| <p>4. 3 Second Scan Delay</p>  <p>M20232_01</p> | <p>This code creates a 3 second delay between scans.</p> |
| <p>5. Disable Duplicate Scan Delay</p>  <p>M20229_01</p> | <p>This code disables duplicate scanning.</p> |