



## Setting up CODE CR1500 Scanner for Rapid Tags as a USB keyboard

The instructions below will program the CODE CR1500 Scanner to properly decode the Rapid Tag Data matrix symbols. More information may be found on the Rapid Lab website: <http://rapidlab.com/scanner-and-software-support/>

1. Unplug the CODE CR1500 from the PC.
2. While holding the trigger pressed, plug the reader into the USB port on the PC and hold for 5-10 seconds. You will hear 5 rapid beeps and then you can let go of the trigger. The unit is now in Boot Mode.
3. To reset the CODE CR1500, simply hold the trigger down again for approximately 5-10 seconds until it reboots. The reader will vibrate first and then beep several times and is now reset.
4. Next, simply scan the following codes shown in the table below.

Required Codes:	
<p>Remove previous programming</p>  <p>CC004361_02</p>	<p>Custom settings requiring suffix &lt;Enter&gt;</p>  <p>CC004482_03</p>

Additional optional codes on the page below.

## Optimal Codes:

1. Scan the following barcode to disable suffix <ENTER>



M20208\_01

2. Continuous Scan On



M20224\_01

3. 1 Second Duplicate Scan Delay



M20230\_01

4. 3 Second Duplicate Scan Delay



M20232\_01

1. This code disables the suffix <ENTER>.

2. This code allows for continuous scanning on your CR1500.

3. This code creates a 1 second delay between scans.

4. This code creates a 3 second delay between scans.

5. Disable Duplicate Scan Delay



M20229\_01

5. This code disables duplicate scanning.